

			Netto	Brutto
1	VO-0350-1320	Vocas Cheese plate for top bars Canon EOS C200	195,00	232,05
2	VO-0350-1335	Vocas H-cheese plate for Panasonic AU-EVA1	155,00	184,45
3	VO-0350-1300	Vocas Cheese plate for Sony PMW-F5 & F55	135,00	160,65
4	VO-0350-1340	Vocas Cheese plate for Arri Alexa Mini	155,00	184,45
5	VO-0350-1361	Vocas Cheese plate MKII for Sony PXW-FS7 / FS7 II	135,00	160,65
6	VO-0350-1400	Vocas Separate top handgrip	295,00	351,05
7	VO-0350-1700	Vocas Schulterstütze MKII für Sony PXW-FS7 / FS7 II	595,00	708,05
8	VO-0360-0525	Vocas 15 mm General lens support	195,00	232,05
9	VO-0360-0550-01	Vocas 15 mm Lens support for Sony 28-135 lens	125,00	148,75
10	VO-0360-0600	Vocas 15 mm Lens mount adapter support	195,00	232,05

Gruppe 3 GmbH
Frankfurter Ring 247
80807 München
Tel: +49 89 36 81 84 32
Fax: +49 89 36 84 84 99
E-Mail: verkauf@gruppe3.de

Gruppe 3 GmbH
Helmholtzstr. 2 - 9
10587 Berlin
Tel: +49 30 39 800 890
Fax: +49 30 39 800 8911
E-Mail: berlin@gruppe3.de